




Instructions for use











2. Screw in the part 2 (x2) to the part 3.




3. Remove the end cap of ④ and let it pass through ①.



- 4. Insert 4 into 1, and rotate the cap
 - * The smartphone holder can be replaced by the tablet holder in the same way.



5. Hold the smartphone with 4. Make sure that the buttons on your smartphone aren't pressed while doing this.



6. Attach the clip 5 on the camera lens of your smartphone. Depending on the smartphone cover's thickness, it may be difficult to do so. In that case, remove the cover before attaching it.



7. Start recording with the smartphone camera and move 1, 4 and 5 while checking the screen to adjust the position and orientation. You can change the direction of the lens part (5) by turning it.

Important notes

- · To play TCG online, you'll need video call apps such as ZOOM, SKYPE or DISCORD. While playing, we suggest checking your smartphone's battery from time to time.
- The weight capacity is approximately 600g, so please note that the arm may bend slightly downwards if it exceeds.
- · Depending on the smartphone model, the edge of the clip may be slightly reflected and the view may be slightly narrowed.
- · Since the magic clip uses a special lens, the reflection of light inside may cause the so-called 'mirage' phenomenon. This may vary from slightly visible to almost non visible depending on the camera setting position, clip attachment, angle, lighting, card color, playmat color, etc., and the location and size of the 'mirage' may vary. While this shouldn't be a problem for a normal remote gameplay, please note that it may happen.



In case there is a problem with the product, please contact us. We will exchange it.

TOYGER Official Shop: info@toyger.jp